

MAN B&W 662VT2BF-140 Diesel Engine spares

[Contact: AGV - Injectores Navais Unipessoal, LDA](#)

Description	Code	Quantity
Stuffing box body, variant 3	A1S227/1	1
Flange (stuffing box)	A1S228/1	1
Sealing ring, pos.3	VTO9S25	1
Sealing ring, pos.4	VTO9T25	3
Oil scrapper ring, pos.5 + spring VTO9B88	A4S258 (011.09.503)	4
Oil scrapper ring, pos.6 + spring VTO9B88	A4S259 (011.09.504)	4
Oil scrapper ring, pos.8 + spring VTO9B88	A4S256 (011.09.501)	2
Oil scrapper ring, pos.9 + spring VTO9B88	A4S261 (011.09.506)	4
Spring	VTO9B88	8
Cylinder liner	VT05AU01	1
O-ring for cyl.liner	VT05B18	30
Cylinder cover, drw. A-1115, 011-06-101	VT06M01	1
Safety valve, drw. B-1303	VT20E01	6
Exhaust valve body drw. B1306	VT12K11	3
Valve guide, lower	1837C14	1
Valve guide, upper	1837C15	4
Exhaust valve bush, lower	1838D23	2
Exh valve bush, upper	VT12K17	1
Spring disc, lower	VT12D85	6
Spring disc, upper	VT12B42	5
Slide block VT12A43	VT12A43	3
Spring ring	801D81	2
Spring disc, centre	1878B6	4
Damper (011.25.209 & piston 011.25.210)	1395A56	1 set
Return valve	011.25.350	29
Non-return valve (exh.valve drive) spring	1477B82	7
Piston crown	AOS175 (011.10.210/110)	8
Piston skirt	AOS38 (011.10.102)	2
Telescopic pipe with bush (drw. A-2076)	VT11F10/B20	5
Fuel pump housing with plunger Ø38mm	VT36F01/VT36N01	5
Fuel pump housing with plunger Ø35mm	VT36F01/VT36N01	4
Fuel injector, assy with atomizer	VT17C01	6
Atomizer	VT15A05/VT17A05	20
Nozzle	VT17C55 / VT17 E55	20
HP fuel pipe	AOS189	18
Bearing shaft bush	011.12.209	22
Compensator (expansion piece)	013.57.000	9
Pump valve, complete	011.39.180	28



